

INSTRUCTION TAG  
MODELS "A", "D" & "E" .22 LONG RIFLE



USE .22 LONG RIFLE  
CARTRIDGES ONLY

READ CAREFULLY  
INSTRUCTIONS  
ON OTHER SIDE.

HANDLES ALL STANDARD MAKE OF .22 LONG  
RIFLE CARTRIDGES, HIGH VELOCITY AND  
LOW PRESSURE. BEST RESULTS WITH LUBRI-  
CATED BULLET.

## INSTRUCTIONS

### AUTOMATIC SLIDE LOCK

Located on right hand side of frame at top of stock. Automatically locks slide open when pistol is used as a single shot, and when the last cartridge has been fired from the magazine if pistol is used as an automatic. This slide lock does not operate automatically when magazine is removed, but can be hand operated by pulling slide back as far as it will go, pushing up on knurled head of the latch and then releasing slide. The operation of this slide lock is up and down, and not in and out.

### IMPORTANT

Do not attempt at any time to close slide by forcing down on knurled head of latch without first pulling back on slide to relieve tension. Holding in this position push down on latch and release slide.

When using as a single shot leave the magazine in, and pull slide back until it is caught by slide lock. Insert cartridge in barrel, and release slide by hand. If you grip pistol as in firing you will find that the trigger finger comes in contact with the knurled head of the latch at about the middle, and can be used for releasing the slide.

**TO FILL MAGAZINE**—Do not force cartridges down through lips at top of magazine. Insert head of cartridge at front of magazine and slide backwards, at same time holding down magazine button so as to relieve pressure of magazine spring.

### ADJUSTABLE REAR SIGHT

This sight has two lock screws, one at the rear of the slide, and one coming up against this screw from underneath. To adjust, first lock slide open, turn gun over, and the main locking screw will be seen inside of the slide coming up from the bottom. It is the larger of the two screws. Loosen the screw, and then loosen the screw coming in from the back of the slide. This will allow you to move sight base for windage and sight slide for elevation. When correct adjustment is obtained tighten screw at the back of slide, and then the main locking screw underneath.

**TO TAKE DOWN**—First remove magazine and cock the hammer by opening sliding bolt "A" and letting it snap forward. Then push in on plunger "B" located at rear end of bolt "A"; at the same time pull down on take-down lever "C" and draw bolt back off frame. Be sure and hold lever "C" down all the way until bolt is removed.

**TO RE-ASSEMBLE**—Pull down on take-down lever "C" and insert front end of bolt on rear of frame, sliding forward as far as the hammer. Depress hammer and push bolt "A" forward to a closed position. Push in on plunger "B" and take-down lever "C" will snap up into place. *Caution! Be sure that take-down lever "C" snaps up into place before firing the gun.*