

## INSTRUCTIONS FOR USE OF HIGH STANDARD G.380 AUTOMATIC PISTOL

### TO LOAD PISTOL

1. Remove magazine from pistol by depressing magazine catch located at rear of magazine opening in the frame and the the same time withdrawing magazine from pistol.
2. Load magazine with five .380 automatic cartridges.
3. Insert loaded magazine into magazine opening in the pistol frame being sure that the magazine is completely up in the frame and the magazine catch has moved forward over the magazine base into the locked position.
4. Cock hammer to full cocked position. Draw slide assembly fully to rear and release. Slide assembly will snap forward inserting live cartridge into the barrel chamber. Gun is now ready to fire.
5. To put the gun on safe, safety lock should be moved vertically upward until lug on the safety lock engages notch in the side of the slide assembly. Gun is now in safe position.
6. Move the safety lock downward and gun is again ready to fire.

### TO DISASSEMBLE PISTOL

1. Remove magazine from the pistol frame.
2. Using thumb of the right hand against the serrated portion of the barrel lock, press the barrel lock forward in a direction toward the front sight and grasping the barrel with the left hand draw the barrel forward off the frame of the pistol. The slide assembly is then moved forward away from the hammer and slides readily off the pistol frame.
3. The gun is now field stripped into the following components: Magazine, pistol frame, barrel, and slide assembly.

### TO REASSEMBLE PISTOL

1. Grooves in the slide assembly must be lined up with the ways on the pistol frame; slide assembly is moved to the rear until it makes contact with the hammer.
  2. Move the barrel lock forward compressing the barrel lock spring and engage grooves on the barrel with ways in pistol frame, moving barrel to the rear until approximately  $\frac{1}{4}$ " of barrel locking lug is visible. Release barrel lock. Move barrel rearward until barrel lock snaps into position.
- CAUTION: Be sure that the barrel is fully engaged with its corresponding surface on the barrel
3. Insert magazine and pistol is now fully reassembled ready for firing.

# THE HIGH STANDARD MANUFACTURING CORPORATION



MANUFACTURERS OF "HI-STANDARD" PRODUCTS  
1817 DIXWELL AVENUE · HAMDEN 14, CONN.

## MODEL G-380 PARTS LIST AND PRICES

<u>PART NO.</u>	<u>PART NAME</u>	<u>PRICE</u>
1A	Frame	\$ 21.00
2	Hammer	1.50
3A	Hammer Pin	.20
4	Hammer Strut	.20
5	Hammer Strut Pin	.20
6	Hammer Spring	.20
7	Hammer Spring Plunger	.20
8	Sear	1.50
9A	Sear Pin	.20
10	Sear Spring	.20
11	Sear Spring Plunger	.20
12A	Sear Bar	.45
13	Sear Bar Spring	.20
14	Safety	1.10
15	Safety Spring	.20
16A	Side Plate	.20
17	Trigger	1.50
18A	Trigger Pin	.20
19	Trigger Spring	.20
20	Trigger Spring Plunger	.20
21A	Trigger Pull Pin	.30
22A	Ejector	.20
23A	Ejector Pin	.20
24	Barrel Catch	1.20
25A	Barrel Catch Pin	.20
26	Barrel Catch Spring	.20
28A	Magazine Catch	.50
29A	Magazine Catch Pin	.20
30A	Magazine Catch Spring	.20
34A	R. H. Grip	.80
35A	L. H. Grip	.80
36A	L. H. Grip Escutcheon	.08
73A	R. H. Grip Escutcheon	.08
37A	L. H. Grip Screw	.08
77A	R. H. Grip Screw	.08
38A	Slide	.20
39A	Driving Spring	.20
40	Driving Spring Plunger	.20
41A	Driving Spring Plug	.20
42	Driving Spring Plug Pin	.20

<u>PART NO.</u>	<u>PART NAME</u>	<u>PRICE</u>
43A	Buffer Spring	\$ .20
44	Buffer Spring Plunger	.20
45A	Buffer Spring Plug	.20
46	Buffer Spring Plug Pin	.20
47A	Firing Pin	.50
48	Firing Pin Spring	.20
49	Firing Pin Retaining Pin	.20
50	Extractor	.50
51	Extractor Spring	.20
52	Extractor Spring Plunger	.20
58A	Barrel - 5"	9.00
60A	Magazine Complete	3.00
74	Fixed Rear Sight	1.10
75	Fixed Front Sight	1.00